

# **LABORATORY GUIDE**

## **AUTONOMOUS SYSTEMS**

Alberto Vale, João Luzio, Kevin Alcedo, Marcelo Jacinto, Paulo Nogueira,  
Rui Xavier, Rodrigo Ventura, Luís Custódio

2024/2025

# PRE-REQUISITES: Personal laptop

- **Ubuntu** 20.04 LTS (recommended) (**ROS1 is not supported in 22.04LTS**)
- **Windows or MacOS:**
  1. Dual boot (with one of the Ubuntu versions mention above; not recommended in **MacOS** since is not officially supported in Apple Silicon)
  2. Virtual machine with at least 4GB of RAM and 20GB of space: **VMware** recommended\*, **Parallels**, or **UTM** (not so fast, but with graphical environment)
  3. **WSL** 1 or 2 (2 recommended) + X Server (VcXsrv recommended)\*\*
  4. Lightweight virtual machine: **Multipass** (fast but no graphical environment; use foxglove for visualization)
  5. Using ROS 1 directly on Windows 10 is **not recommended**
  6. Using Docker and [ROS 1 image](#) **not recommended** (unless you are already familiar with it)

\* Check <https://si.tecnico.ulisboa.pt/software/vmware/> for free student license.VirtualBox can also be used, but not recommended.

\*\* Disable access control and add to the .bashrc the following line: “export DISPLAY=<hostname>.local:0”

# PRE-REQUISITES: Laboratory computers

---

- Ubuntu with ROS 1 pre-installed
- Computers are connected to the deec-robots network  
(the same as all robots)
  - Username: acsdc
  - Password: acsdclsd4

# INSTALLING LINUX AND ROS 1

- Each ROS 1 version is linked to an Ubuntu LTS release

Operating System	ROS 1 Version	Python Version
<u>Ubuntu 16.04LTS</u>	<a href="#">ROS Kinetic</a>	2
<u>Ubuntu 18.04LTS</u>	<a href="#">ROS Melodic</a>	2
<u>Ubuntu 20.04LTS</u> (recommended)	<a href="#">ROS Noetic</a>	3
Ubuntu 22.04LTS	Not Supported	---

- Desktop-Full Install is **recommended**
- If you have troubles with the official ROS Noetic installation, follow [these instructions](https://varhowto.com/install-ros-noetic-ubuntu-20-04) (<https://varhowto.com/install-ros-noetic-ubuntu-20-04>)

# RECOMMENDATIONS

## 1. USE TERMINATOR

- On the laptop, run

```
sudo apt-get install terminator
```

### Tips and Tricks

```
ctrl + shift + C (copy)
ctrl + shift + V (paste or use the right button of mouse)
ctrl + shift + O (split the terminal horizontally)
ctrl + shift + E (split the terminal vertically)
ctrl + shift + Z (focus/unfocus a terminal window)
```



## 2. DEVELOP YOUR PROJECT IN PYTHON

# GETTING STARTED WITH ROS

- “Introduction to the Robot Operating System (ROS)”, from Rodrigo Ventura **[mandatory if the first contact with ROS]**
- Short course videos from Rodrigo Ventura and João Avelino **[complementary]**
  - Part 1:  
[https://www.youtube.com/watch?v=3aVYUAj7sr4&t=1205s&ab\\_channel=RodrigoVentura](https://www.youtube.com/watch?v=3aVYUAj7sr4&t=1205s&ab_channel=RodrigoVentura)
  - Part 2:  
[https://www.youtube.com/watch?v=zqpKWHHlgOA&ab\\_channel=RodrigoVentura](https://www.youtube.com/watch?v=zqpKWHHlgOA&ab_channel=RodrigoVentura)



# THE LABORATORY

- Located at the 5<sup>th</sup> floor of the North Tower – Room LSDC4



**WIFI (Pioneers, Alphasbots and Turtlebots):**

**Network:** deec-robots

**Password:** shakeytherobot

**IP range:** 192.168.28.<id>

---

**Lab computers:**

**Username:** acsdc

**Password:** acsdclsd4

# THE LAB COMPUTERS

---

- Lab computers shall be used to test code or to record bag files and NOT for development.
- Check the Wi-Fi connection of the lab computers to deec-robots network (if not working properly, please contact Mr. Manuel Ribeiro (office 5.18, [mrribeiro@tecnico.ulisboa.pt](mailto:mrribeiro@tecnico.ulisboa.pt), phone number 2189 inside Técnico, 218418189 from outside).
- **ROS\_HOSTNAME** AND **ROS\_IP** have been added as an alias in the lab computers, they can also be exported by simply running **EXPORT\_HOST**.  
These export commands are needed in each new terminal that will use ROS to communicate with the robot.



# THE PIONEER ROBOTS

- The Pioneer robots are configured with:
  1. A Raspberry Pi with Ubuntu 18.04LTS and ROS 1 Melodic
  2. The [P2OS ROS package](#)
- Relevant topic of P2OS node:
  - Subscribes:
    - `/cmd_vel` (geometry\_msgs/Twist)
  - Publishes:
    - `/pose` (nav\_msgs/Odometry)
    - `/sonar` (p2os\_driver/SonarArray)
- Hokuyo laser rangefinder:
  - Publishes:
    - `/scan` (sensor\_msgs/LaserScan)



## CREDENTIALS:

**Username:** pi

**Password:** acsdclsd4

**Network:** deec-robots

**Password:** shakekeytherobot

**IP range:** 192.168.28.[17...23]

# THE PIONEER ROBOTS [Connecting]

1. On a new terminal of the Laptop/Lab computer, and SSH into the RPi of the **Pioneer**

```
ssh pi@192.168.28.[17...23]
```

2. Start a roscore instance inside the RPi of the **Pioneer**

```
roscore
```

3. Open another terminal in the Laptop/Lab computer and SSH into the RPi again

```
ssh pi@192.168.28.[17...23]  
roslaunch p2os_driver p2os_driver _port:="/dev/ttyUSB0" (or)  
roslaunch p2os_driver p2os_driver _port:="/dev/ttyUSB0" _use_sonar:="true"
```

If `ipconfig` is not available, use `ip address` or install `net-tools` to run `ifconfig`:  
`apt update`  
`apt install net-tools`

4. Run in the Laptop/Lab computer (or append to you `~/.bashrc` file)

```
export ROS_MASTER_URI=http://192.168.28.[17...23]:11311 [Pioneer/RPi IP]  
export ROS_HOSTNAME=192.168.[27/28].xxx [Lab computer IP/Laptop]  
export ROS_IP=192.168.[27/28].xxx [Lab computer IP/Laptop]
```

# THE PIONEER ROBOTS [Communications]

5. Test the communications: can the computer see the robot's topics?

```
rostopic list
```

6. Interesting topics to query: “/pose”, “/sonar”

```
rostopic echo "/pose"  
rostopic info "/pose"  
rostopic hz "/pose"
```

7. Test motion commands \*

```
rostopic pub /cmd_vel geometry_msgs/Twist '[0.0, 0.0, 0.0]' '[0.0, 0.0, 0.5]' (or)  
rostopic pub -r 1 /cmd_vel geometry_msgs/Twist '[0.1, 0.0, 0.0]' '[0.0, 0.0, 0.0]'
```

8. To record topics in rosbags \*\*

```
rosbag record -a (for all topics)  
rosbag record /<topic name> (for specific topics)
```

\* Check that the motors are enabled, the topic /motor\_state should be 1. If not, press the 'motors' button on the robot. Press again to stop!

\*\* If path unspecified, bags get recorded in the folder where the command is run. See <http://wiki.ros.org/rosbag/CommandLine#record>

# THE PIONEER ROBOTS [Operation]

---

9. Install the teleop package - run in the laptop once **[skip for lab computers]**

```
sudo apt-get install ros-noetic-teleop-twist-keyboard
```

10. Control the robot. On the laptop/Lab computer, run

```
roslaunch teleop_twist_keyboard teleop_twist_keyboard.py
```

# THE PIONEER ROBOTS [Hokuyo rangefinder]

1. To install on your laptop (alternatively connect directly to the RPi on the robot, and skip this step)

```
sudo apt-get install ros-noetic-urg-node
```

2. Connect the Hokuyo and run

```
chmod a+rw /dev/ttyACM0
```

3. Launch the **urg** node on the device you connected the hokuyo (roscore is assumed to be running)

```
roslaunch urg_node urg_node /dev/ttyACM0
```

4. To test with the RVIZ, run on the laptop/Lab computer the following command and see next slide (it is assumed that step 4 from slide 8 was executed)

```
roslaunch rviz rviz
```




Request access to  
Mr. Manuel Ribeiro

# THE PIONEER ROBOTS [Hokuyo rangefinder]

Write “laser”, since no referential was defined.

Add “LaserScan” node



# THE PIONEER ROBOTS [Microsoft Kinect]

1. To use the Microsoft Kinect with the Pioneer robots, you must install a few packages on your laptop. Please follow these steps to install them:

```
sudo apt-get update
sudo apt-get upgrade
sudo apt-get install git-core cmake freeglut3-dev pkg-config build-
essential libxmu-dev libxi-dev libusb-1.0-0-dev
```

```
cd ~/src
git clone https://github.com/OpenKinect/libfreenect.git
cd libfreenect
mkdir build
cd build
cmake -L ..
Make
sudo make install
sudo ldconfig /usr/local/lib64/

cd ~/catkin_ws/src
git clone https://github.com/ros-drivers/freenect\_stack.git
cd ..
catkin buildsource ~/catkin_ws/devel/setup.bash
```



Request access to  
Mr. Manuel Ribeiro

# THE PIONEER ROBOTS [Microsoft Kinect]

2. To run the node that publishes the images coming from the Kinect, you must first run this command on a terminal, after connecting the USB to your computer and the Kinect to the power outlet or the robots:

```
dmesg
```

3. One of the few last lines will contain similar information to this (check the device number and serial number). In this case, the USB device number is 21.

```
[11151.635280] usb 1-2.2: new full-speed USB device number 21 using xhci_hcd
```


4. Now, launch the camera node using this command (replace the *device\_id* by the number you got from the **dmesg** command):

```
roslaunch freenect_launch freenect.launch device_id:=21 depth_processing:=false
```

**NOTE:** If for some reason you can't still see the image from the camera in your computer, then try to replace the *device\_id* by the serial number also shown in **dmesg**.



# THE PIONEER ROBOTS [Charging]



Attention to the buttons!



# THE TURTLEBOT ROBOTS

- The Turtlebots are configured with a Raspberry Pi with Ubuntu 18.04LTS and ROS 1 Melodic
- Relevant topics:
  - Subscribes:
    - `/cmd_vel` (geometry\_msgs/Twist)
    - `/reset` (std\_msgs/Empty)
  - Publishes:
    - `/odom` (nav\_msgs/Odometry)
    - `/tf` (tf2\_msgs/tfMessage)
    - `/scan` (sensor\_msgs/LaserScan)
- Additional resources:
  - [http://wiki.ros.org/turtlebot3\\_bringup](http://wiki.ros.org/turtlebot3_bringup)
  - [http://wiki.ros.org/hls\\_ifcd\\_lds\\_driver](http://wiki.ros.org/hls_ifcd_lds_driver)
  - [http://wiki.ros.org/sensor\\_msgs/Tutorials](http://wiki.ros.org/sensor_msgs/Tutorials)



## CREDENTIALS:

**Username:** user

**Password:** user

**Network:** deec-robots

**Password:** shakeytherobot

**IP range:** 192.168.28.[11...15]

# THE TURTLEBOT ROBOTS [Connecting]

1. On a new terminal of the Laptop/Lab computer, and SSH into the RPi of the **Turtlebot**

```
ssh user@192.168.28.[11...15]
```

2. Start a roscore instance inside the RPi of the **Turtlebot**

```
roscore
```

3. Open another terminal in the Laptop/Lab computer and SSH into the RPi again

```
ssh user@192.168.28.[11...15]
```

4. Sync the robot time [not mandatory]

```
sudo apt-get install ntpdate  
sudo ntpdate ntp.ubuntu.com
```

5. Launch the robot drivers

```
roslaunch turtlebot3_bringup turtlebot3_robot.launch
```

# THE TURTLEBOT ROBOTS [Laptop Setup]

6. Install the Turtlebot3 packages - run in the laptop once **[skip for lab computers]**.

```
sudo apt-get install ros-noetic-dynamixel-sdk
sudo apt-get install ros-noetic-turtlebot3-msgs
sudo apt-get install ros-noetic-turtlebot3
sudo apt-get install ros-noetic-teleop-twist-keyboard
```

If `ipconfig` is not available, use ip address or install `net-tools` to run `ifconfig`:  
`apt update`  
`apt install net-tools`

7. Additional configurations. Run in the Laptop/Lab computer (or append to you `~/.bashrc` file)

```
export TURTLEBOT3_MODEL=waffle_pi
export TURTLEBOT3_NAME=waffle4
export TURTLEBOT3_IP=192.168.28.[11...15]
export TURTLEBOT3_NUMBER=[11...15]
export ROS_MASTER_URI=http://192.168.28.[11...15]:11311
export ROS_HOSTNAME=192.168.[27/28].XXX
export ROS_IP=192.168.[27/28].XXX
```

[TurtleBot3 191919 on the stick]  
[TurtleBot IP]  
[Last numbers of the TurtleBot3 IP]  
[TurtleBot3 IP]  
[lab computer / laptop IP]  
[lab computer / laptop IP]

# THE TURTLEBOT ROBOTS [Communications]

8. Test the communications: can the computer see the robot's topics?

```
rostopic list
```

9. Interesting topics to query: “/odom”, “/scan”

```
rostopic echo "/odom"  
rostopic info "/odom"  
rostopic hz "/odom"
```

10. Test motion commands

```
rostopic pub /cmd_vel geometry_msgs/Twist '[0.0, 0.0, 0.0]' '[0.0, 0.0, 0.5]' (or)  
rostopic pub -r 1 /cmd_vel geometry_msgs/Twist '[0.1, 0.0, 0.0]' '[0.0, 0.0, 0.0]'
```

11. To record topics in rosbags \*

```
rosbag record -a (for all topics)  
rosbag record /<topic name> (for specific topics)
```

\* If path unspecified, bags get recorded in the folder where the command is run. See <http://wiki.ros.org/rosbag/Commandline#record>

# THE TURTLEBOT ROBOTS [Operation]

---

12. Control the robot. On the laptop/Lab computer, run

```
roslaunch turtlebot3_teleop turtlebot3_teleop_key.launch
```

---

## Accessing the robot camera

1. Launch the camera node on the robot



```
roslaunch turtlebot3_bringup turtlebot3_rpicamera.launch
```

2. To see the camera feed, run on the laptop/Lab computer

```
roslaunch rqt_image_view rqt_image_view
```



# THE TURTLEBOT ROBOTS [Charging]



# THE ALPHABOT ROBOTS

- The Alphas are configured with a Raspberry Pi 3 B, Ubuntu 20.04 LTS and ROS 1 Noetic
- Relevant topics:
  - Subscribes:
    - `/cmd_vel` (geometry\_msgs/Twist)
  - Publishes:
    - `/camera/compressed` (sensor\_msgs/CompressedImage)
- Additional resources:
  - [ROS & Python drivers](#)
  - [Raspicam node](#)
  - [Fiducial slam](#)
  - [ROS for waveshare Alphas2](#) (deprecated)

## Warning

These robots do **NOT** have wheel odometry, IMU or LiDAR



## CREDENTIALS:

**Username:** alphabot2

**Password:** alphabot2

**Network:** deec-robots

**Password:** shakekeytherobot

**IP range:** 192.168.28.[50...70]



# THE ALPHABOT ROBOTS [Operation]

1. Open a terminal on a Laptop/Lab computer, and SSH into the RPi of the **Alphabot**

```
ssh alphabot2@192.168.28.[50...70]
```

2. Initialize motion drivers (motor drive & camera servos)

```
cd ~/catkin_ws  
source devel/setup.bash  
roslaunch web_control web_control.launch
```

3. Open a web browser in the Laptop/Lab computer and go to the **web\_control** link:

```
https://[192.168.28.[50...70]:8000/
```

4. Test motion control directly from the browser!

# THE ALPHABOT ROBOTS [Camera]

1. Open a terminal on a Laptop/Lab computer, and SSH into the RPi of the **Alphabot**

```
ssh alphabot2@192.168.28. [50...70]
```

2. Launch the camera

```
source ~/catkin_ws/devel/setup.bash  
roslaunch raspicam_node camerav2_1280x960.launch
```

3. Open a new terminal using X11 on a Laptop/Lab computer, and SSH into the RPi of the **Alphabot**

```
ssh -X alphabot2@192.168.28. [50...70]
```

4. Visualize the camera stream

```
rqt_image_view
```

# THE ALPHABOT ROBOTS [Camera]

5. (Alternate) Rviz cannot handle compressed images, but if you prefer Rviz to visualize images, it is necessary the following in your laptop and subscribe the topic /raspicam\_node/image\_raw:

```
sudo apt-get install ros-noetic-image-transport
```

```
roslaunch image_transport republish compressed in:=/raspicam_node/image raw out:=/raspicam_no/image_raw
```

6. (Alternate) Try out foxglove! (<https://foxglove.dev/>)

**To learn more about the Alphabot drivers:** <https://github.com/Kons-5/ROS-for-the-Alphabot2>

**Make sure to checkout the repo's [wiki](#) for more details (i.e. camera calibration, Aruco detection, etc.)**

*Consider contributing this “home-grown” open-source project throughout the course 😎*

# THE ALPHABOT ROBOTS [Communications]

7. Run in the Laptop/Lab computer (or append to you ~/.bashrc file)

```
export ROS_MASTER_URI=http://192.168.28.[50..70]:11311      [Alphabot-RPi IP]
export ROS_HOSTNAME=192.168.28.xxx                        [Lab computer IP/Laptop]
export ROS_IP=192.168.28.xxx                              [Lab computer IP/Laptop]
```

8. Test the communications: can the computer see the robot's topics?


```
rostopic list
```

9. Interesting topics to query: “/raspicam\_node/image/compressed”

```
rostopic echo "/raspicam_node/image/compressed"
rostopic info "/raspicam_node/image/compressed"
rostopic hz "/raspicam_node/image/compressed"
```

# THE ALPHABOT ROBOTS [Charging]

Charge via micro-USB (5V)



# ROS CHEAT-SHEET

## Relevant terms to search

Package	Bag
Node	Launch Files
Topic	Parameters
Publisher	TF
Subscriber	RVIZ
Message	Gazebo

## Graphical user tools

```
roslaunch rviz rviz

roslaunch rqt_image_view rqt_image_view

rqt (can be used to monitor)

roslaunch rqt_tf_tree rqt_tf_tree

roslaunch rqt_plot rqt_plot
```

## Terminal user tools

```
roscore
roslaunch <package_name> <node_name>
roslaunch <package_name> <launch_file>
roscd <package_name>

rostopic list
rostopic info <topic_name>
rostopic hz <topic_name>

roscd list
roscd info <node_name>

roscd play <options>
roscd record <options>

roscd create-pkg <options>

roscd service list
roscd service call <options>

roscd msg list
```

# ROS EXTRA NOTES

- Often forgotten – set the environment variables used by ROS

```
source devel/setup.bash
```

- Confirm the definition of the ROS packages path

```
echo $ROS_PACKAGE_PATH
```

- ROS/Linux editors: vim or nano [nano is recommended]
- Make use of the .bashrc file

```
source /opt/ros/noetic/setup.bash  
source ~/catkin_ws/devel/setup.bash  
export EDITOR='nano -w'
```

- Copy a file from the robot to your laptop/Lab computer

```
scp <robot_username>@<robot_ip>:<path_to_file> <location_in_your_computer>
```

IMPORTANT



- Explore the use of `roslaunch` and launch files
- Bag files may occupy too much space.

**Suggestion:** record only the required topics and include compression

```
rosbag record -j <topics>
```

- If problems are detected, run

```
roswtf
```

- To install dependencies of a package, use `rosdep`

```
sudo apt-get install rosdep  
rosdep init  
rosdep install <package-name>
```

- ROS log files are located at

```
~/.ros/log
```



# ROS EXTRA RESOURCES

- Official ROS website:  
<https://www.ros.org/>
- ROS Wiki:  
<http://wiki.ros.org/>
- Core ROS Tutorials:  
<http://wiki.ros.org/ROS/Tutorials>
  - Beginner Level **[all bullets recommended]**
  - Intermediate Level **[roslaunch tips]**
- TF2 Tutorials:  
<http://wiki.ros.org/tf2/Tutorials>  
<https://articulatedrobotics.xyz/ready-for-ros-6-tf/>
- Robot Model:  
[http://wiki.ros.org/robot\\_model\\_tutorials](http://wiki.ros.org/robot_model_tutorials)
- Visualization:  
<http://wiki.ros.org/visualization/Tutorials>
- Navigation:  
<http://wiki.ros.org/navigation/Tutorials>
- MATLAB **[use ROS to record bags and read them in MATLAB]**  
Open and parse rosbag log file (since R2022a supports ROS Noetic): <https://www.mathworks.com/help/ros/ref/rosbag.html>
- Aruco detector:  
[https://wiki.ros.org/aruco\\_detect](https://wiki.ros.org/aruco_detect)
- Camera Calibrator:  
[http://wiki.ros.org/camera\\_calibration](http://wiki.ros.org/camera_calibration)

# Extra software suggestions

- Recommended to use **Git** in your project's files to track their changes over time. Git also allows for file backup and sharing.  
**Attention:** share the project only with members of the group and, eventually, with professors of the course. Do not enable public access.
- MATLAB can be used to produce graphics from ROS bag files (MATLAB supports ROS Noetic since R2022a): open and parse rosbag log file (MATLAB recommended only for plotting purposes)  
<https://www.mathworks.com/help/ros/ref/rosbag.html>)


```
bag = rosbag(filename)
bagInfo = rosbag('info',filename)
rosbag info filename
```

# Extra software suggestions (cont.)

- **Foxglove** is a Rviz alternative, with data management and timeline visualization capabilities.

Available for Linux,  
Windows and macOS.

<https://foxglove.dev/>



- Select a **physical robot** for a first trial
- Connect to the robot and **list topics**
- **Visualize in real time sensor data** (e.g. Rviz, or Foxglove)
- **Move the robot** using the keyboard, while visualizing sensor data
- **Record a bag**, transfer it to an external computer, and visualize the data with **rosbag play**